
List of figures

Figure 1	
Static discharge points	18
Figure 2	
Connector for the battery pack assembly	21
Figure 3	
Installing the circuit card in the card cage	23
Figure 4	
Circuit card grid	36
Figure 5	
Switch functions and areas	42
Figure 6	
Switch default settings	43
Figure 7	
DPNSS1/DASS2 configuration	52
Figure 8	
APNSS configuration	53
Figure 9	
ISL high-speed programming	54
Figure 10	
ISL low-speed programming	55
Figure 11	
NT8D72 DIP switch settings	79

